



Grill & Outdoor Cooking Safety

08

Keep outdoor cooking outdoors and away from anything that can burn.

FIRE SAFETY TIPS

- 1 Use grills outside only. Never use a charcoal or gas grill inside a home, garage, enclosed porch, or tent.
- 2 Place the grill well away from siding, deck railings, eaves, branches, and other combustible materials.
- 3 Keep children and pets at least 3 feet away from the grill area.
- 4 Never leave a lit grill unattended.
- 5 For propane grills, check the hose and connections for damage or leaks before use. For charcoal grills, let coals cool completely before disposal in a metal container.

REMEMBER

Keep a clear path to the grill and never move a hot grill into an enclosed area.